

# Important Notes About This Guide

Last Modified on 02/24/2025 4:02 pm EST

## Overview

This guide covers how to install and configure the Lenel connector. Before completing the steps in this guide, you must speak to your CSM about installing and configuring Connect and the Dispatch connector.

## Related Information/Setup

Please refer to the [Lenel OnGuard Connector Installation Guide](#) for information on installing a Lenel™ OnGuard Connector.

Please refer to the [Connect User's Guide](#) for information on editing the connectors, registering and mapping devices, and creating rules.